

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

028731-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

-

7. UNIT AGREEMENT NAME

-

8. FARM OR LEASE NAME

M. Dodd "B"

9. WELL NO.

7

10. FIELD AND POOL, OR WILDCAT

Square Lake Cbg S.A.

11. SEC., T., E., M., OR BLK. AND
SURVEY OR AREA

Sec. 14, T-17-S, R-34-E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Sunray DX Oil Company ✓

3. ADDRESS OF OPERATOR

P. O. Box 1416, Roswell, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

1980' FNL & 1980' FWL of Sec. 14, T-17-S, R-34-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3628 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

Convert to water injection ☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Move in pulling unit.
2. Pull rods and tubing.
3. Run Lane Wells GR-N with Collar Locator 1000'-TD.
4. Determine Metex productive interval from log.
5. Set Baker C.I. bridge plug approximately 20' below bottom of Metex.
6. Perforate injection interval of Metex w/4 bullets per foot. Acidize w/500 gals BDA. Swab load.
7. Run tubing w/Baker Model "AD" packer and set packer approximately 30' above the Metex injection interval.
8. Install injection head. Commence water injection.

NOTE: This well is currently a producer making 1 BOPD.

RECEIVED

FEB 8 1967

U. S. G. GEOLOGICAL SURVEY
ARTESIA OFFICE

RECEIVED
FEB 7 - 1967
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

B. F. Brawley

B. F. Brawley

TITLE

District Engineer

DATE

2-3-67

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED
FEB 7 1967
R. L. BECKMAN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.