

9. Pull work string and spot a 100' cement plug from 1050' to 950'. WOC and tag cement plug.
10. Pull work string and spot a 100' cement plug from 750' to the surface.
11. Leave heavy mud between cement plugs.
12. Nipple down BOP's.
13. Erect P&A marker.
14. Rig down pulling unit.
15. Clean up and grade location to original condition.