

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPL.

Form approved
Budget Bureau No. 42 R1424

3. LEASE DESIGNATION AND SERIAL NO.

LC-028784-b

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Keely "B"

9. WELL NO.

9

10. FIELD AND POOL, OR WILDCAT

Grayburg-Jackson

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 26, T-17S, R-29E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

General American Oil Company of Texas

3. ADDRESS OF OPERATOR

P. O. Box 128 Loco Hills, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)

At surface

1980' FSL and 1980' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3575' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETION

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON*

SHOOTING OR ACIDIZING

ABANDONMENT*

REPAIR WELL

CHANGE PLANS

(Other)

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

The following work was completed June 24 — 29, 1981:

1. Spot 25 sacks cement to plug off perforations 1232'-1224'.
2. Ran casing stretch survey to confirm 7" casing free as shown on the Cement Bond Log.
3. Using string shot, backed off casing at first free collar (820'), and pull 7" casing out of hole.
4. Spot 150' cement plug to cover Base of Salt (785') and casing stub (820'). Top of plug @ 720'.
5. Spot 100' cement plug over 8-5/8" casing shoe @ 411'. Top of plug @ 364'.
6. Set 10 sack surface plug.
7. Install permanent dry hole marker.

Additional report will be submitted at end of 4 well abandonment program.

18. I hereby certify that the foregoing is true and correct

SIGNED

M. S. Lanning

TITLE

Engineer

DATE

June 30, 1981

(This space for Federal Agency Use)
(Orig. Sgd.) PETER W. CHESTER

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

SEP 23 1981

FOR

JAMES A. GILLHAM
DISTRICT SUPERVISOR

*See Instructions on Reverse Side