Submit 3 Copies to Appropriate District Office

State of New Mexico Energy, Minerals and Natural Resources Department

\sim 1/ \sim	orm C-103 Revised 1-1-89
------------------	-----------------------------

DISTRICT I P.O. Box 1980, Hobbs NM 88240

OIL CONSERVATION DIVISION

2040 South Pacheco

WELL API NO.	-	
30-015-03160		
5. Indicate Type of L	ease STATE	FEE

DISTRICT II Santa Fe, New Mexico 87505	30-013-03100	
811 South First, Artesia, NM 88210	5. Indicate Type of Lease STATE FEE FEE	
DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 87410	6. State Oil & Gas Lease No.	
	B-7596	
SUNDRY NOTICES AND REPORTS ON WELLS		
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS).	7. Lease Name or Unit Agreement Name	
1. Type Of Well:		
OIL GAS OTHER	Robinson State	
2. Name of Operator Mack Energy Corporation	8. Well No. 4	
3. Address of Operator	9. Pool name or Wildcat	
P.O. Box 960, Artesia, NM 88211-0960	Grbg Jackson SR Q Grbg SA	
4. Well Location		
Unit Letter D:330 Feet From The North Line and	990 Feet From The West Line	
Section 27 Township 17S Range 29E	NMPM Eddy County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3540' GR		
Check Appropriate Box to Indicate Nature of Notice,	Report, or Other Data	
	JBSEQUENT REPORT OF:	

PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING **TEMPORARILY ABANDON** CHANGE PLANS COMMENCE DRILLING OPNS PLUG AND ABANDONMENT **PULL OR ALTER CASING** CASING TEST AND CEMENT JOB OTHER: OTHER

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Mack Energy Corporation proposes to plug and abandon as follows:

- 1. Notify OCD 24 hours before starting.
- 2. Set CIBP @ 2522' w/35' cement cap.
- 3. Circulate hole w/mud. 700
- 4. Perforate casing @ 950', bottom of salt and squeeze 40 sx, WOC and tag.
- 5. Perforate casing @ 329', 50' below 8 5/8 casing shoe and squeeze 40 sx, WOC and tag
- 6. Set 10 sx plug from 60' to surface.

7. Install dry hole marker.

210'- inside From 329' to

cont must be 0'-60'in

tion above is true and complete of the best of my knowledge and belief I hereby certify that the info

5/20/02 Production Analyst TITLE -SIGNATURE -DATE

TELEPHONE NO TYPE OR PRINT NAME Crissa D. Carte

(This space for State Use)

APPROVED BY-

TITLE .

CONDITIONS OF APPROVAL, IF ANY:

And the state of t

1