30-015-03172

Ugrid - 13837 Prop - 6104 Poul - 28509

(1) And Att Rec'd. 8-16-66 1 - Lamma Ray neutron Log



to Appropriate	State of New Me		~	Form C-1	IO3 dst	
Submit 3 Copies District Office	Energy, Minerals and Natural Re	esources Department		Revised 1	-1-89	
<u>DISTRICT I</u> P.O. Box 1980, Hobbs NM 88240	OIL CONSERVATIO 2040 South Packet		WELL API NO. 30-015-03172		1	
DISTRICT II 811 South First, Artesia, NM 88210	Santa Fe, New Mex	ico 87505	5. Indicate Type o	f Lease STATE	FEE	
DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 87410	2 4 14 2 4 1		6. State Oil & Gas B-514	Lease No.		
	ICES AND REPORTS ON WE					
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PIREOFAVED O A DIFFERENT RESERVOIR. USE "APPLICATION FOR PEROFO" - ARTESIA (FORM C-101) FOR SUCH PROPOSALS)			7. Lease Name or Unit Agreement Name			
I. Type Of Well: OIL GAS WELL WELL	OTHER	A STATES ZINOLO	GJ West Coop	Unit		
2. Name of Operator V Mack Energy Corporation			8. Well No. 10			
3. Address of Operator			9. Pool name or Wildcat			
P.O. Box 960, Artesia, NM 88211-0960			Grbg Jackson S	SK Q Grbg SA		
4. Well Location Unit Letter:198	30 Feet From The South	Line and66	60 Feet From	n The West	Line	
Section 28	Township 17S R	ange 29E	NMPM	Eddy	County	
Interview Interview 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3570' GR						
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data						
NOTICE OF INTENTION TO: SUE			SEQUENT F	REPORT OF:		
	PLUG AND ABANDON	REMEDIAL WORK		ALTERING CASIN	G 🗌	
	CHANGE PLANS	COMMENCE DRILLING	GOPNS.	PLUG AND ABANI		
PULL OR ALTER CASING		CASING TEST AND CE				
OTHER:		OTHER				

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

7/11/2000 PLUG AND ABANDON well as follows:

Called OCD and get verbal approval from Mike Stubblefield, faxed reports to him. POH laying down pump rods and tubing.

7/12/2000 RIH perforate 2 holes at 1252' and 2 holes at 400', RIH w/2 3/8" tubing spot 25sx (100') plug over perfs at 2019', pull up to 1252' and squeeze 100' in and out 4 1/2" csg with 45sx plug. pull up hole wait 1 1/2 hour, RIH tag plug at 1180', POH laying down 2 3/8" tubing, tie on to 4 1/2" csg and pump 105sx full circ between 4 1/2 and 8 5/8" csg, circ cmt between both to surface shut in. rig down. Install Dry Hole Marker.

		(man for the
I hereby certify that the formation above is true a SIGNATURE		ion Analyst 7/25/00
TYPE OR PRINT NAME	Crissa D. Carter	TELEPHONE NO. (505)748-1288
(This space for State Use) APPROVED BY CONDITIONS OF APPROVAL, I ANN) TITLE	APR 19 2002