

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/-
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B-514

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	G-J West Coop. Ut.
Tenneco Oil Co. ✓	8. Farm or Lease Name
3. Address of Operator	G-J West Coop. Ut.
P. O. Box 1031, Midland, Texas	9. Well No.
4. Location of Well	1
UNIT LETTER M 877 FEET FROM THE South LINE AND 908 FEET FROM	10. Field and Pool, or Wildcat
THE West LINE, SECTION 28 TOWNSHIP 17 South RANGE 29 East NMPM.	Grayburg-Jackson
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3550 GR	Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>
Convert to Water Injection	

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1708.

In accordance w/Order WFX No. 245
Propose to:

1. Pull rods, pump & tubing.
2. Run tension type packer on 2-3/8" tubing.
3. Set packer @ approx. 2600'.
4. Connect wellhead to water injection line.
5. Commence injecting water into Oolitic zone of San Andres formation thru perfs. 2705-2836.

RECEIVED

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. F. Carnes TITLE Dist. Prod. Eng. DATE Dec. 13, 1966

APPROVED BY L. A. Gressett TITLE DATE DEC 1 1966

CONDITIONS OF APPROVAL, IF ANY: