

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

NM OIL
Drawer DD
Artesia, NM
FORM APPROVED
Budget No. 1004-0133
Expires: March 31, 1993

c151

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
Mack Energy Corporation

3. Address and Telephone No.
P.O. Box 960, Artesia, NM 88211-0960

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
SEC. 11 T-17-S R-30-E 1980' FNL & 330' FEL

5. Lease Designation and Serial No.
LC-029338-B

6. If Indian, Allotment or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
Harvard Fed #4

9. API Well No.
30-015-04118

10. Field and Pool, or Exploratory Area
Square Lake GB SA

11. County or Parish, State
Eddy, New Mexico

CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- Squeeze 50 sacks cement below packer @ 2750'; wait on cement; tag at 2848'; spot 35 sacks cement to bring cement above liner at 2712'
- Load Hole with mud
- Perforate casing at 1310'; squeeze 35 sacks cement; wait on cement; no tag; re-squeeze with 60 sacks cement; wait on cement; no tag; spot 60 sacks cement at 1700'; wait on cement; tag cement at 1320'; cement plug was low; spot 25 sacks cement at 1320'; wait on cement; tag cement at 1310'; plug was low; spot 25 sacks cement at 1310'; wait on cement; tag cement at 1292'; tag cement top 18' above perforation; spot 25 sacks cement at 1292'; wait on cement; tag cement top at 1018'
- perforate casing at 708'; squeeze with 70 sacks cement; wait on cement; tag at 483'
- Perforate casing at 60'; circulate cement to surface with 70 sacks cement; between 7" - 10-3/4 leaving 7" full.
- Job completed 6-6-95

Prd ID-2
8-18-95
RHA

Approved by: [Signature]
Title: [Blank]
Date: [Blank]

I hereby certify that the foregoing is true and correct

Signed: [Signature]

Title

Date 6-6-95

(This space for Federal or State office use)

Approved by: [Signature]

Title

REGIONAL ENGINEER

Date JUN 26 1995

18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side