

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRI JATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

LC-029338(a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ **Convert to Water Injection**
2. NAME OF OPERATOR
WINDEFOHR OIL COMPANY
3. ADDRESS OF OPERATOR
1202 First National Bank Bldg., Fort Worth, Texas 76102
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
**440' from the south and 2200' from the west lines of
Section 12-17S-30E.**

7. UNIT AGREEMENT NAME

Grayburg Jackson (S.A.)

8. FARM OR LEASE NAME

9. WELL NO.

33

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson - GB-SA
11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**Sec. 12-17S-30E**

12. COUNTY OR PARISH 13. STATE

Eddy**New Mexico**

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

Convert to Water InjectionPULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐**X**

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to convert this well to water injection by the following work:

1. Pump 20 bbls. hot water down casing and pump out to clean hole.
2. Inject water down casing into open hole until pressure resistance is developed.
3. Set gravel and cal seal bridge above pay. Cement 4½" O.D. liner from above pay to approximately 50' above 7" casing shoe.
4. Clean out to bottom. Run 2-3/8" O.D. upset tubing internally lined with cement with tension packer on bottom of tubing. Set packer below top of liner, and resume water injection.

RECEIVED
JUN 24 1969
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Ralph L. Gray

TITLE

ConsultantDATE **June 24, 1969**

(This space for Federal or State office use)

APPROVED
JUN 24 1969

TITLE

DATE

R. L. BECKMAN

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for special instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of packing of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

RECEIVED
OCT 10 1963
FEDERAL BUREAU OF INVESTIGATION
U.S. DEPARTMENT OF JUSTICE