

N. M. Q. C. C. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN DUPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

LC-030570 (a)

6. INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐ Convert to Water Injection		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR WINDFOHR OIL COMPANY		8. FARM OR LEASE NAME Stevens "A" Tract 2	
3. ADDRESS OF OPERATOR 1202 First National Bank Building, Fort Worth, Texas 76102		9. WELL NO. #3	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* At surface 1980' from North and West lines of Sec. 13-17S-30E.		10. FIELD AND POOL, OR WILDCAT Grayburg-Jackson, Gb, SA	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3727 D.F.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 13-17S-30E
		12. COUNTY OR PARISH Eddy	13. STATE New Mexico

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☐
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) Convert to Water Injection	☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is proposed to convert this producing well to a water injection by the following method:

1. Clean open hole by lowering tubing to bottom of hole and pump 50 barrels of hot water down casing. Remove water by pumping well down.
2. Pull rods and tubing, run logs and caliper surveys.
3. Cement 4½" O.D. J-55, 9.5# liner from bottom of hole to approximately 50 feet above 7" casing shoe. Test top of liner for shut-off.
4. Perforate 4½" liner in San Andres pays, using sand jet.
5. Acidize perforations with small quantities.
6. Run tubing internally coated with plastic and set tension packer in upper portion of 4½" liner. Inject water down tubing.

18. I hereby certify that the foregoing is true and correct

SIGNED Ralph L. Gray TITLE Consulting Engineer.

(This space for Federal or State office use)

APPROVED BY J. A. [Signature]
CONDITIONS OF APPROVAL, IF ANY:

TITLE

RECEIVED
JUN - 8 1967
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment: data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.