

DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

(Other District
verse side)

on re-

Budget Bureau No. 42-101

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		5. LEASE DESIGNATION AND SERIAL NO. NM 0467932	
2. NAME OF OPERATOR Atlantic Richfield Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P. O. Box 1710, Hobbs, New Mexico 88240		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 330' FNL & 990' FEL (Unit letter A)		8. FARM OR LEASE NAME W. D. McIntyre "E"	
14. PERMIT NO.		9. WELL NO. 4	
15. ELEVATIONS (Show whether OF, RT, CR, etc.) 3638' GR		10. FIELD AND POOL, OR WILDCAT Grayburg Jackson OGSA	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 36 21-17S-34E	
		12. COUNTY OR PARISH Eddy	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	PLUG OR ALTER CASING
FRACTURE TREAT	MULTIPLE COMPLETION
SHOOT OR ACIDIZE	ABANDON*
REPAIR WELL	CHANGE PLANS
(Other)	Plug & Abandon ☒

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	REPAIRING WELL
FRACTURE TREATMENT	ALTERING CASING
SHOOTING OR ACIDIZING	ABANDONMENT*
(Other)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

TD 3235'. Presently completed in Grayburg Jackson San Andres OH section 2918-3265'. This well has been shut in since September, 1963 because it was uneconomical to produce. No other zones of interest exist and the well is not needed in future waterflood plans. 9-5/8" OD 36# casing set @ 520' & cmt'd w/30 sx. 7" OD 24# csg set @ 2918' & cmt'd w/100 sx.

Propose to plug & abandon this well in the following manner:

1. Rig up, install BOP, remove bull plug & 1 jt of tbg.
2. RIN w/7" CIBP, set @ 2850'. Cap BP w/35' of C1 C cmt cont'g 4% gel. Fill hole w/heavy gelled mud.
3. Spot 100' C1 C cmt cont'g 4% gel inside 7" csg from 1500-1600'.
4. Perforate 7" csg w/4 holes @ 520'.
5. RIN w/7" cmt retr, set retr @ 460'.
6. Displace C1 C cmt thru retr & circulate 9-5/8" X 7" csg annulus to surface. If cmt will not circulate, then cmt squeeze perfs @ 520'.
7. Spot 10 sx cmt @ surface, install regulation dry hole marker, clean & level location.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature]
(This space for Federal or State office use)

TITLE Dist. Drlg. Supv.

DATE 1/20/76

RECEIVED
JAN 22 1976
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

APPROVED BY [Signature]
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side