

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN THE STATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

MI-074939

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Gissler "B"

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Grayburg-Jackson, CBG, SA

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 24-17S-30E

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☐ OTHER

Convert to Water Injection well

2. NAME OF OPERATOR

WINDPOUR OIL COMPANY

3. ADDRESS OF OPERATOR

1202 First National Bank Building, Fort Worth, Texas 76102

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)

At surface

660' from North and West lines of Sec. 24-17S-30E.

RECEIVED

14. PERMIT NO. 170 1967

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Convert to Water Injection

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This form is submitted to replace program submitted June 8, 1967, for converting this producing well to a water injection well.

1. Clean hole by lowering tubing to bottom and pump 50 barrels of hot water down casing. Remove water by pumping well dry.

2. Pull rods and tubing, run Gamma Ray-Sonic and caliper logs.

2-A. After reviewing logs, well will be deepened 40 to 50 feet if it appears desirable.

3. Load casing with water, and continue filling hole with water until water level in casing stands at approximately the surface.

4. Run injectivity profile survey to locate zones taking water.

5. Cement 4 1/2" O.D. J-55, 9.5# liner from top of shot hole (Approximately 475') to 50' above 7" casing shoe. Test top of liner with 1800 psi. pressure for shut-off. Drill out to bottom of hole.

6. Run tubing internally coated with plastic and set tension packer in upper portion of 4 1/2" liner. Inject water down tubing.

18. I hereby certify that the foregoing is true and correct

SIGNED

Ralph L. Gray

TITLE

Consulting Engineer.

DATE

June 27, 1967

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL IF ANY:

TITLE

DATE

APPROVED

JUN 29 1967

R. L. BEEKMAN

ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices; either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.