

RECEIVED

Form 9-331
Dec. 1973

Form Approved.
Budget Bureau No. 42-R1424

UNITED STATES SEP 22 1982
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY O. C. D.
ARTESIA, OFFICE

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☐ gas well ☐ other Water Injection

2. NAME OF OPERATOR

General American Oil Company of Texas

3. ADDRESS OF OPERATOR

P.O. Box 128 Loco Hills, New Mexico 88255

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

AT SURFACE:

AT TOP PROD. INTERVAL: 2310' FSL and 2232' FWL

AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other) ☐

☐
☐
☐
☐
☐
☐
☐
☐
☐

5. LEASE
LC-060529
6. IF INDIAN, ALLOTTEE OR TRIBE NAME
7. UNIT AGREEMENT NAME
8. FARM OR LEASE NAME
Beeson "F"
9. WELL NO.
13
10. FIELD OR WILDCAT NAME
Loco Hills
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 31, T-17S, R-30E
12. COUNTY OR PARISH
Eddy
13. STATE
New Mexico
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
3562' DF

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

DATA: NO SURFACE CASING

7" 23# casing @ 2800' with 394 sacks.

1. Dig small workover pit.
2. Pull Tubing
3. Spot 100' Plug from 2825' - 2725' to cover open hole section. (25' outside and 75' inside of 7").
4. Perforate 4 holes @ top of Yates (1260'), and squeeze 55 sacks of cement into formation. (Continued on Back).

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Rendell N. Hawkins TITLE Field Supt. DATE September 21, 1982
Rendell N. Hawkins

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

5. Perforate 4 holes @ top of salt (495'), and squeeze 55 sacks of cement into formation.
6. Perforate 4 holes @ water zone (390' - 400'), and squeeze 55 sacks of cement into formation.
7. Set 10 sack surface Plug.
8. Erect permanent well marker.
9. Clean, Level, and Rip location and roads.
10. Re-seed Location and Road to Federal Specifications.