	Operator G.P.T. Well Feature 55 Unit C Section 5 Township 17 API # 30-015 15	Range _3	31
i	1		
Toc PAIC			
144	E 100 plus in out		
505t	E SALT Place		
	Ext. The section		
	Toone		
2501-			
29b)			
7/29 21			
10 0x	3500 - fet 5'h Liner		

~	TOPS
Salt 10x0	
B. Salt 1800	
Yates Side	
Glorieta	
Delaware	
Bone Sp.	
Abo	
Wolfcamp	
Morrow	
Devonian	
Fusselman	
Other	

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up.
 Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0'- 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.