

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instructions re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

N.M. 074935

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Loce Hills A Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**10 - 17S - 30E**

12. COUNTY OR PARISH

Eddy

13. STATE

N. Mex.**SUNDRY NOTICES AND REPORTS ON WELLS**
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL ☐ WELL GAS ☐ WELL OTHER ☒ **Convert for Water Injection**

2. NAME OF OPERATOR

Anadarko Production Company

3. ADDRESS OF OPERATOR

P. O. Box 67, Loce Hills, New Mexico 882554. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface**660' FSL & 1980' FWL Section 10, T-17S, R-30E
Eddy County, New Mexico**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3697 GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) **Convert for Water Injection**PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)***RECEIVED**

1. Rig up well servicing unit; pull tubing and rods.

2. Perforate additional Grayburg Zones.

3. Acidize.

4. Run 2 3/8" plastic lined tubing with Johnston 51" injection packer.

5. Load annulus with fresh water and chemical.

6. Set packer.

7. Equip for water injection.

8. Place well on injection according to N.M.O.C.C. Order R 4830.

9. No B. O. P. program planned.

FEB 24 1975**O. C. C.
ARTESIA, OFFICE****RECEIVED****JAN 15 1975****U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO****Order R 4830.**

18. I hereby certify that the foregoing is true and correct

SIGNED

**Original Signed by
Jerry E. Buckles**

TITLE

Area Supervisor

DATE

January 7, 1975

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to permit certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations in Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; details (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of and casing liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.