

C15F

Form 31a-3
December 1990

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

11-8-9 1994

FORM APPROVED
Budget Bureau No. 1004-1135
Expires September 30, 1990

5. Lease Designation and Serial No.

NMNM 7752

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

ANDERSON FEDERAL No. 1

9. API Well No.

3001520565

10. Field and Pool, or Exploratory Area

ANDERSON PENN

11. County or Parish, State

EDDY, N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

PARKER & PARSLEY DEVELOPMENT CO. ✓

3. Address and Telephone No.

P.O. BOX 3178, MIDLAND, TX. 79702 - (915) 683-4768

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660 FS & 1980 FEL, SECTION 7, T-17-S, R-30-E

12 CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection

Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form 1

13 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

PROPOSAL (ESTIMATED START, 1-12-94)

1. Recover tbq & prodn pkr set CIBP @ 10800'. Dump 35' cmt on T/plug.
2. Attempt to pump into &/or locate suspected 5 1/2 csq leak. Cmt sqz as req'd.
3. Perf & cmt sqz T/Wolfcamp @ 8650, thru C.R. set at 8600', w/ 60 SX.
4. Perf & sqz 8 5/8 shoe: Perfs/3550; C.R. @ 3450'; Leave 35' cmt on T/C.R.
5. Cut & recover approx. 1160' of 5 1/2 & 8 5/8 csq.
6. Spot 60 SX stub plugs over cut-off csq's & tag.
7. Spot 11 3/4 shoe plug, 425' to 325' & tag. NOTE: If above stub plug covers shoe, abort.
8. Spot 50' surface plug. Install D.H. marker.
9. Remove all surface eqpt, backfill & clean location.
10. Rip surface of location following final clean-up.
11. Re-seed exposed surface in spring, as per BLM specs.

ADDITIONS

At suggestion by NMOCB; (1) Set 25 SX plug at 5200' & (2) Cover DVT @ 2796' w/ cmt when sqz 8 5/8 shoe plug.

14. I hereby certify that the foregoing is true and correct

Signed Bob Yeates BOB YEATES

Title CONSULTANT

Date 1-11-94

(This space for Federal or State office use)

Approved by Adrian Salameh
Conditions of approval, if any:

Title Petroleum Engineer

Date 2/8/94