

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1001 0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 074935

6. If Indian, Allottee or Tribe Name

7. If Unit or C.A. Agreement Designation

8. Well Name and No.

Loco Hills "A" Fed #3

9. API Well No.

30-015-20579

10. Field and Pool, or Exploratory Area

Grayburg-Jackson-Queen-

11. County or Parish, State San Andres

Eddy County, NM

SEP 13 9 07 AM '93
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Anadarko Petroleum Corp.

3. Address and Telephone No.

PO Drawer 130, Artesia, NM 88211-0130 (505) 677-2411

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 1980' FWL, Sec 15, T17S, R30E.

NM OIL CONS. COMMISSION

Drawer DD

Artesia, NM 88210

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non Routine Fracturing

☐ Water Shut Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. RUPU. TOH with rods and tbg.
2. Set CIBP at 2585' on tbg and circulate hole with salt gel mud. TOH with tbg.
3. RU wireline and spotted 35' cement on CIBP at 2585' using a dumpbailer. This plug covers Grayburg Formation top.
4. Set CIBP at 1280' and spotted 100' cement on top of it. This plug isolates base of salt and squeeze holes at 1270'.
5. Set CIBP at 520' and spotted 35' cement on top of it. This plug isolates top of salt.
6. Spotted 100' cement from 457' up to 357'. This plug covers 8 5/8" casing shoe.
7. Spotted a 50' surface plug.
8. Cut off all casing and anchors below ground level; set dry hole marker; will rip and reseed location as per BLM rules and regulations.

P & A on 08-17-93.

Post ID-2
10-15-93
P & A

14. I hereby certify that the foregoing is true and correct

Signed

Mike Brewell

Title Field Foreman

Date 09-07-93

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date

9/28/93

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instructions on Reverse Side

2-11-93

ANADARKO

P.O. DRAWER 130

ARTESIA, NEW MEXICO 88210

(505)

Anadarko

Loco Hills Federal "A" 3-15

