

C/SF

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

JAN 18 1994

2. Name of Operator

SOCORRO PETROLEUM COMPANY

3. Address and Telephone No.

P.O. BOX 37 LOCO HILLS 88255 (505)677-3223

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1000' FNL & 2350 FWL, SEC 18, T17S, R31E

5. Lease Designation and Serial No.
LC-029548-A

6. If Indian, Allottee or Tribe Name

NA

7. If Unit or CA, Agreement Designation

NA

8. Well Name and No.

C.A. RUSSELL #11

9. API Well No.

30-015-21258

10. Field and Pool, or Exploratory Area

GRAYBURG-JACKSON POOL

11. County or Parish, State

EDDY COUNTY, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other

Put Well on Pump

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 11/16/93 Well flowing to battery. Flow well down to working tank
- 11/17/93 RU. Pump was stuck. Strip out of hole w/rods and tbg. Found hole in top of 2-3/8" tbg. Changed out 10 bad jts. Pickup 6-1/4" bit and RIH. Tagged fill @ 3504'. Pack off well head. Leave well open to tank overnight. SD.
- 11/18/93 RU pump truck. Circulate and drill well clean to PBTD @ 3518'. Circulate well bore clean. Drop standing valve and press test tbg to 3000#. Held ok. RD pump truck. RIH w/fishing tool on sand line. Fish standing valve. POH w/tbg. Lay down bit and bit sub. RIH w/production string of tbg. Pick up new pump. RIH w/pump and rods.
- 11/19/93 Well pumping 100% water

JAN 14 1994

NEW MEXICO

14. I hereby certify that the foregoing is true and correct

Signed

[Signature]

Title OPERATIONS MANAGER

Date 12-13-93

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any: