8-15-91	Pull sucker rod pump and rods. Picked up 4 1/2" packer on 2 3/8" tubing and WIH. Set packer at 3320'. Well pumping from perfs 3336'-3404' only. (Keely zone)
8-28-91	Unseat packer and POOH. Pick up 4 1/2" RBP and WIH. Set RBP @ 3170'.
8-29-91	Picked up 4 $1/2$ " packer on tubing and WIH Set packer at 3060'. Testing perforations (3113'-3136').
9-06-91	Removed existing pumping unit. Installing a larger unit. (228)
9-09-91	228 Pumping unit installed. Pull sucker rod pump and sucker rods. Unseated packer and start out of hole with tubing.
9-10-91	Pick up 4 1/2" RBP and packer and GIH. Set RBP @ 2990'. Pull packer 2712' and set.
10-09-91	Pulled rods and sucker rod pump. Installed BOP. Unseat packer and POOH. Pick up retrieving tool for RBP and WIH. Retrieved RBP and POOH with same Removed BOP. Ran sucker rod pump and rods.
10-31-91	Pumped, 61 bbls. of oil and 195 bbls of water
11-01-91	Temp. Dropped from Report.