Drawer DD

Artesia., M

SF/ Jile

N.M.

Form 9-331 (May 1963)

16

UNITED STATES

SUBMIT IN TRIPLICATE

Other instructions on reverse side)

Output

Outp

Form approved. Budget Bureau No. 42-R1424. 5. LEASE DESIGNATION AND SERIAL NO.

LC-029020-D 6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Eddy

GEOLOGICAL SURVEY						
SUNDRY	NOTICES	AND	REPORTS	ON	WELLS	

(Do not use this form for prot Use "APPLI	·			
OIL SAS WELL OTHER		4400 4 4 4000	7. UNIT AGREEMENT NA	ME
2. NAME OF OPERATOR	/	MAR 1 1 1982	8. FARM OR LEASE NAM	(E
Southland Royalty Con	фану /		Dale H. Parke	
3. ADDRESS OF OPERATOR		O. C. D.	9. WELL NO.	
1100 Wall Towers West	, Midland, Texas 79701	ARTESIA, OFFICE	2	
4. LOCATION OF WELL (Report location See also space 17 below.) At surface	10. FIELD AND POOL, OF	•		
940' FEL & 2310' FSL,	Grayburg-Jackson (7R-Q-GB-SA) 11. SEC., T., B., M., OR BLE. AND SURVEY OR AREA			
			Sec. 15, T-17-	S, R-30-E
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)		12. COUNTY OR PARISH	13. STATE
	3682' GR		Eddy	N.M.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF REPAIRING WELL FRACTURE TREAT MULTIPLE COMPLETE FRACTURE TREATMENT ALTERING CASING SHOOT OR ACIDIZE ABANDON* SHOOTING OR ACIDIZING ABANDONMENT* REPAIR WELL CHANGE PLANS (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) (Other) Squeeze water zone

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1. MIRU pulling unit, POH w/rods & tbg. Install BOP.
- 2. RU WL truck and set CIBP @ 2972', POOH.
- 3. RIH w/drillable retainer on WL and set @ 2954', POOH.
- 4. RIH w/tbg & sting into retainer.
- 5. Squeeze perfs from 2959-2966' w/300 sxs Class "C" cmt w/2% CaCl.
- 6. Pull out of retainer & leave 1 sack on retainer, POOH.
- 7. Wait 8 hrs on cmt and GIH w/4 3/4" bit and drill out retainer & CIBP.
- 8. Run tbg & rods and place on test.

OIL & GAS U.S. GEOLOGICAL SURVEY ROSWELL, NEW MEXICO

S. I hereby cortify that the foregoing is true and correct SIGNED	TITLE District Operations	Engineerate 3-2-82
(This space for Federal or State office use)		ACCEPTED FOR RECORD
APPROVED BYCONDITIONS OF APPROVAL, IF ANY:	TITLE	DATE
*Se	e Instructions on Reverse Side	U.S. GEOLÓGICAL SURVEY