Form 3160-5 (June 1990)

## **UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT**

N.M. Oil Co., s. Division FORM APPROVED 811 S. 1st Street

Budget Bureau No. 1004-0135 Expires: March 31, 1993

CIS F

Artesia, NM 8821052834 Signation and Serial No.

## **SUNDRY NOTICES AND REPORTS ON WELLS**

LC-028731B 6. If Iridian, Allottee or Tribe Name

	TOLOLICATE	<ol><li>If Unit or CA, Agreement Designation</li></ol>
	TRIPLICATE	
Type of Well Oil Well Gas Well Other Injection	1314151617 L	8. Well Name and No.
Name of Operator		M. Dodd "B" #49
Marbob Energy Corporation Address and Telephone No.		9. API Well No.
P.O. Box 227, Artesia, NM 88210	arcen FD	30-015-25168 10. Field and Pool, or Exploratory Are
Location of Well (Footage, Sec., T., R., M., or Survey Description		Gyburg-Jackson (SR, Q, GB, SA
Unit E: 2310 FNL, 840 FWL, Sec14.T17S, R29E		11. County or Parish, State
	/1	47/
		Eddy, NM
CHECK APPROPRIATE BOX(s) TO	INDICATE NATURE OF NOTICE, REPO	RT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACT	rion
Notice of Intent	Abandonment	Change of Plans
	Recompletion	New Construction
X Subsequent Report	Plugging Back	Non-Routine Fracturing
Final Abandonment Notice	Casing Repair	VVater Shut-Off
	☐ Altering Casing	Conversion to Injection
	Other	Dispose Water
3. Describe Proposed or Completed Operations (Clearly state all directionally drilled, give subsurface locations and measured a 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole	and true vertical depths for all markders and zones pertinent o e w/9.8# mud	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)  ed date of startirg any proposed work. If well is to this work.)*
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265	and true vertical depths for all markders and zones pertinent o e w/9.8# mud 840 woc g 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night	Completion or Recompletion Report and Log form.) ed date of starting any proposed work. If well is to this work.)*
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. from the first content of the conte	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 20 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night com 60' to surface	Completion or Recompletion Report and Log form.) ed date of starting any proposed work. If well is to this work.)*
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. fro 9. 5-31-01 Pump 50sxs. class "C" neat cmt be	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	Complision or Recompletion Report and Log form.) ed date of starting any proposed work. If well is to this work.)*
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. from the first content of the conte	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	Complision or Recompletion Report and Log form.) ed date of starting any proposed work. If well is to this work.)*
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. fro 9. 5-31-01 Pump 50sxs. class "C" neat cmt be	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	Completion or Recompletion Report and Log form.) ed date of starting any proposed work. If well is to this work.)*
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. fro 9. 5-31-01 Pump 50sxs. class "C" neat cmt be	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	Complision or Recompletion Report and Log form.) ed date of starting any proposed work. If well is to this work.)*
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. frog 5-31-01 Pump 50sxs. class "C" neat cmt be 10. 6-04-01 cut off well head install dry hole materials.	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	completion or Recompletion Report and Log form.)  ed date of starting any proposed work. If well is to this work.)*  s no tag
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. frog 5-31-01 Pump 50sxs. class "C" neat cmt be 10. 6-04-01 cut off well head install dry hole materials.	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	completion or Recompletion Report and Log form.)  ed date of starting any proposed work. If well is to this work.)*  s no tag
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. frog 5-31-01 Pump 50sxs. class "C" neat cmt be 10. 6-04-01 cut off well head install dry hole materials.	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	completion or Recompletion Report and Log form.)  ed date of starting any proposed work. If well is to this work.)*  s no tag
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 37. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. frog 5-31-01 Pump 50sxs. class "C" neat cmt be	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	completion or Recompletion Report and Log form.)  ed date of starting any proposed work. If well is to this work.)*  s no tag
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 3 7. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. frog 9. 5-31-01 Pump 50sxs. class "C" neat cmt be 10. 6-04-01 cut off well head install dry hole many control of the state of the sta	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	completion or Recompletion Report and Log form.)  ed date of starting any proposed work. If well is to this work.)*  s no tag
directionally drilled, give subsurface locations and measured at 1. 5-24-01 Set CIBP @ 2370 w/35' cmt. on top 2 5-25-01. RIH tag cmt. @ 2335 circulate hole 3 5-29-01. Spot 25 sx. class "C" neat cmt. @ 4. 5-30-01 RIH tag cmt @ 616 5. 5-30-01 Perforate 4 holes @ 435 set pkr. @ 6. 5-30-01 Sqz 80sxs. class "C" neat cmt. @ 3 7. 5-31-01 Tag cmt. @ 265 8. 5-31-01 Spot 10 sxs. class "C" neat cmt. fro 9. 5-31-01 Pump 50sxs. class "C" neat cmt be 10. 6-04-01 cut off well head install dry hole materials.	and true vertical depths for all markders and zones pertinent to e w/9.8# mud 840 woc 2 30' sqz 100sxs. class "C" neat cmt woc 4 hrs 30' displace to 200' woc over night cm 60' to surface etween 8 5/8 & 5 1/2 cassing	completion or Recompletion Report and Log form.)  ed date of starting any proposed work. If well is to this work.)*  s no tag

