

Operator Prime Service
 Well Dalton Federal #1
 Unit H Section 29 Township 17 Range 29
 API # 30-015-25259

TOPS

Salado	~400'	
Bear E. Lr	622'	*
Ly. Co.	806'	*
7 Rivers	904'	
Bowers	1456'	
Quinn	1688'	
Greenburg	2078'	
San Andres	2378'	

← Plug 60' - 0' Surface

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

133 1/8" @ 350'
CIRC

← Plug 400' TAG

Per. Co. 100' - 150'
1925-2200
2400-2500

← Plug 300' TAG

← Plug 100' TAG

SV2 @ 3495'
CIRC

← Plug 3495' TAG

TO 350'

[Handwritten signature]