

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

CONTACT RECEIVING
OFFICE FOR NUMBER
OF COPIES REQUIRED
(Other instructions on
reverse side)
BLM & CARLSBAD

BLM Roswell District
Modified Form No.
NM60-3160-4

5. LEASE DESIGNATION AND SERIAL NO.
NM-45223

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Empire Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Wildcat 61-SR-8-6-SA

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

6, T-17S, R-29E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐ JAN 7 9 39 AM '91

2. NAME OF OPERATOR
TOM SCHNEIDER

3. ADDRESS OF OPERATOR
505 N Big Spring St., Suite 204, Midland, TX 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State regulations.
See also space 17 below.)
At surface
1,980' FEL - 2,100' FNL of Section 6,
T-17-S, R-29-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)
3726.6 KB 18' above GL

35. Area Code & Phone No.
(915) 682-6340
687-3078

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANE

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Please refer to attached schematic drawing of casing and perforations presently in place.
The well tested to be non-commercial from the Paddock perforations 3,975 to 4,079'.

~~It is proposed to~~ Plug & Abandon as follows:

Did:

1. Load hole with 9# per gallon mud.
2. Spot sufficient cement to provide at least 205' fill from 3925' to 4130' in 5 1/2" casing.
Tsg plug.
3. Cut 5 1/2" casing at 800' and pull.
4. Spot sufficient cement to provide 100' across 5 1/2" casing stub to extend 50' above casing stub. Tag plug.
- 4A. SPOT CEMENT PLUG FROM 373' - 273'. TAG PLUG.
5. Cement 50' surface plug.
6. Weld or cement 4" x 4" ^{10'} above surface marker.

Notify BLM at (505) 887-6544 at least 24 hours before plugging.

USE CLASS 'C' CEMENT W/2% CALCIUM CHLORIDE MIXED W/6.3 GALS WATER/SACK
P&A ON 7/11/90.

18. I hereby certify that the foregoing is true and correct

SIGNED William F. Grauten

Schneider & Grauten

TITLE Assistant Operations Manager DATE

(This space for Federal or State office use)

APPROVED BY William F. Grauten
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

Approved as to...
Limiting under...
surface...
*See Instructions on Reverse Side

RECEIVED
8 20 AM '90