

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED

Budget Bureau No. 1004-0135
Expires March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other
2. Name of Operator DEVON ENERGY CORPORATION (NEVADA)
3. Address and Telephone No. 20 NORTH BROADWAY, SUITE 1500, OKLAHOMA CITY, OKLAHOMA 73102 (405) 235-3611
4. Location of Well (Footage. Sec., T., R., M., or Survey Description) 2310'FNL & 110'FEL of Section 18-T17S-R31E

5. Lease Designation and Serial No. LC-054908
6. If Indian, Allottee or Tribe Name
7. If Unit or CA, Agreement Designation
8. Well Name and No. Hudson Federal #9
9. API Well No. 30-015-28790
10. Field and Pool, or Exploratory Area Grayburg-Jackson Field
11. County or Parish, State Eddy County, NM

CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION	
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
SUBJECT TO LIKE APPROVAL BY STATE	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Altering Casing	<input checked="" type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other _____	<input type="checkbox"/> Dispose Water
	(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Convert to water injection well as follows:

1. Clean out wellbore to PBTD of 3762'.
2. RIH with injection packer on 2 3/8" (IPC) tubing and set at $\pm 2750'$.
3. Inject through existing perforations 2806' - 3717' (OA).



RECEIVED
1997 SEP 29 P 1:06
BUREAU OF LAND MGMT.
ROSWell OFFICE

14. I hereby certify that the foregoing is true and correct

Signed <u>Charles H. Carleton</u>	Title <u>Sr. Engineering Tech.</u>	Date <u>September 23, 1997</u>
(This space for Federal or State office use)		
Approved by <u>(ORIG. SGD.) ALEXIS C. SWOBODA</u>	Title <u>PETROLEUM ENGINEER</u>	Date <u>OCT 2 1997</u>
Conditions of approval, if any:		