

Frank
10-58
9-5

2-21-79

Snouder

with 608-20
20' - 100' and with
1000-55 and 1000-100-

9-5 * 10" 230-20

8'-716-S

* 7" 1330-100 + 30 tons clay - split csg. c. - 1076 2y. 100 sec.

5 1/2" 1440-20" in 1941

plug in to 28' 6" in 1965

* set 4 1/2" - 2118 - 300 sec. line.

9-21-65 set SP @ 1730 + 1650-36 1671-7-

Q.

✓ set ETC 1630 + cap w/ 35' cement

spot 35 sec plug - 1200 -

" 22 sec plug - 500

✓ 10 sec plug at surface
small bitum plug.

Called Frank 2-22-79 8:45 AM. He will get crew out
dig around 7' sec if Csg. still in hole
3-1-79 looks like 10-7' + 4 1/2"
Cement at surface between strings

Frank Yater Called @ 9:00 AM. 3-1-79
gave him the above plugging

Copy

For #1-D-24-1826

The only thing that he has done is
that, after he has removed
all junk from the 2 other places
and back the machine