

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

APR 16 1992

WELL API NO.

5. Indicate Type of Lease

STATE ☐

FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name

Hondo L F E

8. Well No.

1

9. Pool name or Wildcat

Atoka Penn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☐

GAS
WELL ☒

OTHER

2. Name of Operator

M W J Producing Company

3. Address of Operator

400 West Illinois Ste. 1100 Midland, Texas 79701

4. Well Location

Unit Letter P : 990 Feet From The South Line and 990 Feet From The East Line

Section 19

Township 18-S

Range 26-E

NMPM

Eddy

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3442' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1) Spot 50 sacks cement at 9070' w.o.c. Tag at 8326'.

2) Load hole with mud.

3) Perforate at 7250'

4) Set 4-1/2" cement retainer at 7199' squeeze w/ 25 sacks cement.

5) Cut 4-1/2" casing at 5561' Lay down.

6) Spot 35 sacks cement at 5611' 50' in 4-1/2" casing stub w.o.c. Tag at 5475'.

7) Spot 35 sacks cement at 4350'.

8) Spot 35 sacks cement at 2300'.

9) Spot 35 sacks cement at 1341' w.o.c. Tag at 1269' spot 14 sacks cement.

10) Spot 35 sacks cement at 350'.

11) Spot 10 sacks cement at surface and set up P. & A. marker.

Part ID-2
8-21-92
YxH

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

Agent

DATE

8/7/92

8-1-92

915/

TYPE OR PRINT NAME

Sabra Fury

TELEPHONE NO.

682-5216

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: