TOPS

	Operator $(F_{1})$ $(f_{2})$ $(f_{3})$ $(f_{3$	Range 🚔
	- 65 aufou Plug	
	- 300' - 7779 - 7 <b>8</b>	
7''	- 77A5 - 77A5 - 77A5 - 77A5 - 77A5 - 77A5	

Yates		
T. Salt		
B. Salt		
Glorieta		
Bone Sp		
Abo		
Wolfcamp		
Morrow		
Devonian		
Fusselman		
Other		
<u> </u>		
<u>57 1130</u>		

ڡؘ

- Contact OCD 24 hrs. prior to any work d
- Salt gel mud consisting of 10# brine with of gel per barrel must be placed between plug
- Install dry hole marker as per rule 202.B.
- Plugs are to be set from point indicated u Plugs must not be less than 100' or 25 Sa of cement, whichever is greater.
- Shoe and stub plugs will be 50' above an below shoe or stub and tagged.
- Surface plug will be from 0'- 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.