

Operator C.F.M. A.J. Co
Well Kindle #2
Unit A Section 24 Township 13 Range 22
API # 30-0 15 -- 00003

TOPS

Yates _____
T. Salt _____
B. Salt _____
Glorieta _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other Queen 300
S.A. 1130

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

← 60' Surface Plug

← 300'

440' TOP @ 50'

7" ← 9.20 - 7.29
9.20' 04
 1012'