

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIP. RE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 028805 B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Hudson 'B'

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Empire Abo

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 3-T18S-827

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Cities Service Oil Company

3. ADDRESS OF OPERATOR

Box 69 - Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface

2310' FNL & 990' FWL Sec. 3-T18-R27E

Eddy County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3577 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

Perform Remedial Work

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

O.T.D. 5664 OPBTD 5630 Prep. to perf. and squeeze gas zone that is channeling down casing to producing perfs. in the following manner:

1. Rig up workover rig and pull tubing.
2. Set CI bridge plug above prod. perfs. (5562-5614)
3. Perforate gas zone w/2 hole @ approx. 5513'.
4. Acidize and squeeze thru perfs. @ 5513.
5. Do cement and push CI bridge plug down the hole to OPBTD 5630.
6. Test old perfs. (5562-5614) natural and if necessary acidize to bring well back to a flowing status.
7. Run tubing and install wellhead equipment.

RECEIVED

DEC 14 1970

U.S. GEOLOGICAL SURVEY
ARTEZIA, OFFICE

RECEIVED

DEC 14 1970

U.S. GEOLOGICAL SURVEY
ARTEZIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

ROBERTSON

TITLE

District Admin. Supervisor

DATE

12-11-70

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

ACCEPTED FOR RECORD PURPOSES
DEC 14 1970
Date
ACTING District Engineer

In the future, obtain U.S.G.S. Approval
prior to commencing work as required
by Oil & Gas Operating Regulations
*See Instructions on Reverse Side
30 UFR 221.58

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between, and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.