

NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANITARY	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

JUL 8 1975

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B - 11083</b>
7. Unit Agreement Name <b>Artesia State Unit</b>
8. Farm or Lease Name <b>Tract No. 7</b>
9. Well No. <b>2</b>
10. Field and Pool, or Wildcat <b>11083</b>
12. County <b>Eddy</b>

SUNDRY NOTICES AND REPORTS ON WELLS **O. C. C.**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS. **ARTESIA, OFFICE**)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator <b>Anadarko Production Company</b>
3. Address of Operator <b>P. O. Box 67, Loco Hills, New Mexico 88255</b>
4. Location of Well UNIT LETTER <b>B</b> , <b>330</b> FEET FROM THE <b>North</b> LINE AND <b>1650</b> FEET FROM THE <b>East</b> LINE, SECTION <b>23</b> TOWNSHIP <b>18 S</b> RANGE <b>27 E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>3499</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spot 100 sx cement plug in open hole from T. D. 1879' to bottom of 7" casing @ 1721' and 50' into 7" casing @ 1671'.
2. Shut in 4 hours; wait on cement; tag plug.
3. Shoot 7" casing off @ 1500'.
4. Pull 7" casing.
5. Spot 35 sx cement plug through Queen Section 1500' to 1400'.
6. Spot 6 sx mud.
7. Spot 35 sx cement plug through Seven Rivers Section 950' to 850'.
8. Spot 8 sx mud.
9. Spot 35 sx cement plug 50' in and 50' out of 8" casing @ 319'.
10. Spot 10 sx cement plug at surface.
11. Erect dry hole marker, close pits and clean location.

8 1/4" - 319-25  
7" - 1721-50

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed by Jerry E. Buckles TITLE Area Supervisor DATE July 3, 1975

APPROVED BY W. A. Gressett TITLE SUPERVISOR, DISTRICT II DATE JUL 9 1975

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

plugging