

30 c 01908

K-17-18-28

Aceco Petro. Co.

Welch St. #1

* Perforate $4\frac{1}{2}$ " casing @ 50'.
Circulate cement to surface. inside & outside
 $4\frac{1}{2}$ " csg.

$8\frac{5}{8}$ "-510'
w/

T. SALT. 450'

* Perforate $4\frac{1}{2}$ " casing @ 560'.
Squeeze 100' cement Plug inside & outside $4\frac{1}{2}$ " csg. TAS

B. SALT.

* Circulate brine gel to surface

$4\frac{1}{2}$ " csg
2000'

* Run & set CIBP @ 1900'. w/ 35' cement on top.
or set 25 sk cement Plug 1900'-1800'. TAS

TD. 2135' + -