

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED
 NEW MEXICO OIL CONSERVATION COMMISSION
MAR 22 1968
 U. S. G.
 LAND OFFICE

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. 647	
7. Unit Agreement Name -	
8. Farm or Lease Name Reasler Yates State	
9. Well No. 46	
10. Field and Pool, or Wildcat Artesia	
12. County Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator American Petrofina Company of Texas
3. Address of Operator Box 1311, Big Spring, Texas 79720
4. Location of Well UNIT LETTER 0 , 250 ⁷ FEET FROM THE South ⁷ LINE AND 1570 ⁷ FEET FROM THE East ⁷ LINE, SECTION 21 TOWNSHIP 18S RANGE 28E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) -

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>	PLUG AND ABANDONMENT	<input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>	OTHER	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Ran 2100' of 2" EUE tubing and spotted 50 sack cement plug on bottom of 7" casing at 2045'.
2. Pulled tubing.
3. Shot 7" casing off at 1268'.
4. Spotted 25 sack cement plug at 1206'.
5. Spotted 25 sack cement plug at 700'.
6. Pulled 7" casing.
7. Shot off 8 5/8" casing at 128' and pulled.
8. Loaded hole with 10# mud.
9. Set 5 sack cement plug at surface and placed 4 1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman **Cliff Chapman**

TITLE Petroleum Engineer

DATE March 21, 1968

APPROVED BY

R. L. Stamm

TITLE

Oil & Gas Inspector

DATE

APR 5 1968

CONDITIONS OF APPROVAL, IF ANY: