

TOPS

TOC $\xrightarrow[\text{Cap @ 50\%}]{250'}$

8" @ 339'
25 x 25.
10" hole

← 60' Surface plug

← 389' TAG

← 650'

1314' ← TOC calc @ 50%

?
7" @ 1718
SC 3x5.
8" hole

1718' TAG

TD 2172'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, **if no cement exists.**
- * Plugs to be tagged will be indicated.

MLB