

SANTA FE, NEW MEXICO 87501

OCT 7 1982

O. C. D.

ARTESIA, OFFICE

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-11540	
7. Unit Agreement Name	
8. Farm or Lease Name	
Vandeventer	
9. Well No.	
4	
10. Field and Pool, or Wildcat	
Artesia	
12. County	
Eddy	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator
William E. Jeffers	3. Address of Operator
P. O. Box 65, Artesia, NM 88210	4. Location of Well
UNIT LETTER B, 330 FEET FROM THE North LINE AND 1650 FEET FROM THE East LINE, SECTION 22 TOWNSHIP 18South RANGE 28East NMPM.	15. Elevation (Show whether DF, RT, GR, etc.)
	12. County
	Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Filled hole with mud, set cast iron bridge plug at 2200' dump 35' cement on top of plug, pressure up on casing to 1000'. Take stretch on casing, stuck at 360'.

Perforate at 950' set retainer at 870' squeeze 20 sax below 10 sax in, and 5 sax on top. Perforate 475' set retainer at 390', squeeze 20 sax below, 10 sax in and 5 sax on top. Set 15 sax top hole plug set monument.

Post ID-2
10-15-82
P+H

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED

TITLE

DATE

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: