

TOPS

TOC $\frac{167}{\text{Calc @ 50\%}}$

10" @ 305
50 ft
Est. 12" hole

7" 0224
SOSAS

shoe plus
255 - 355 TAG

505 Tnd G

710' TAG

2165' ← Top C.S. @ 40%

2284' T.R.G.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of **all** casing string(s) in the correct footage or sacks required, **if no cement exists.**
- * Plugs to be tagged will be indicated.

MLE