

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>647</b>
7. Unit Agreement Name -
8. Farm or Lease Name <b>Reasler Yates State</b>
9. Well No. <b>19</b>
10. Field and Pool, or Wildcat <b>Artesia</b>
12. County <b>Eddy</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator <b>American Petrofina Company of Texas</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>
4. Location of Well UNIT LETTER <b>G</b> , <b>1840</b> FEET FROM THE <b>North</b> LINE AND <b>2390</b> FEET FROM THE <b>East</b> LINE, SECTION <b>28</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>3540 Gr.</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Spotted 50 sack cement plug on bottom.
2. Filled hole with 10# mud through 2" tubing; pulled tubing.
3. Pulled off 4 1/2 casing at 150'.
4. Ran tubing and filled hole with cement from 150' to surface.
5. Set 4 1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman TITLE Petroleum Engineer DATE March 20, 1968

APPROVED BY [Signature] TITLE  DATE

CONDITIONS OF APPROVAL, IF ANY: