

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	647

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>AMERICAN PETROFINA COMPANY OF TEXAS</b>	8. Farm or Lease Name <b>Resler Yates State</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>	9. Well No. <b>32</b>
4. Location of Well UNIT LETTER <b>H</b> , <b>2390</b> FEET FROM THE <b>North</b> LINE AND <b>780</b> FEET FROM THE <b>East</b> LINE, SECTION <b>28</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> N.M.P.M.	10. Field and Pool, or Wildcat <b>Artesia</b>
15. Elevation (Show whether DF, RT, GR, etc.)	12. County <b>Eddy</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approx. 2-8-71

Spot 50 sk cement plug on bottom (PBSD 2130) through 2" EUE tubing using mud laden fluid as displacing medium

Pull 7" casing (2140')

Spot 25 sk cement plug at 1600' (Queen Sand)

Pull 8-1/4" casing (933')

\* Spot 25 sk cement plug @ <sup>320</sup>275' (bottom of 10" casing)

Place 10 sk cement plug in top of 10" casing & set 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman **Cliff Chapman** TITLE Petroleum Engineer DATE 1/5/71

APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE JAN 7 1971

CONDITIONS OF APPROVAL, IF ANY: \* on next page