

Harvey Ross

Green Lakes 113

Section 28 Township 18 Range 28

30-01S-02078

Lyons	~	600
Timber	~	950
Rivers	~	1350
Queen	~	1350
Graydon	~	2025

Platz 6 - O'surber

TOC
316
CAP

8 5/16" x 1 1/4"

2 of 5 1997-01-01

277- 210901
355000
CNC

← 25sx Plug 1947 Tag

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.