

Operator Dwane Parrish  
 Well Tomas Allen #9  
 Unit I Section 28 Township 18 Range 28  
 API # 30-015-02103

TOPS

Salt 3  
 Rivers ~ 1050  
 Browns ~ 1375  
 Queen 1564  
 Grayburg 2064

TOC 84' →  
 Calc @ 50%

- \* Contact OCD 24 hrs. prior to any work done.
- \* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- \* Install dry hole marker as per Rule 202.B.2
- \* Plugs are to be set from point indicated up.
- \* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- \* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- \* Surface plug will be from 0' - 60'
- \* Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- \* Plugs to be tagged will be indicated.

8 5/8" @ 378'  
 100 SXS  
 10 3/4" hole

← shoe plug  
 328' to 428' TAG

← 1050'

1808' ← TOC calc. @ 50%

← 2014' TAG

2064' -  
 2083' ← perfs

4 1/2" @ 2098'  
 100 SXS.  
 7 7/8" hole

MLB