

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
647

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator AMERICAN PETROFINA COMPANY OF TEXAS	8. Farm or Lease Name Resler Yates State
3. Address of Operator Box 1311, Big Spring, Texas 79720	9. Well No. 10
4. Location of Well UNIT LETTER I 260 FEET FROM THE East LINE AND 2380 FEET FROM South THE 29 LINE, SECTION 18S TOWNSHIP 28E RANGE 28E NMPM.	10. Field and Pool, or Wildcat Artesia
15. Elevation (Show whether DF, RT, GR, etc.) 3560 Gr	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set cast iron bridge plug at 1950' in 4-1/2" casing. Dumped 2 sacks cement on top of bridge plug.
- Ran 1925' of 2" EUE tubing & filled hole with 10# mud.
- Pulled tubing
- Shot off 4-1/2" casing at 1112' and spotted 25 sack cement plug through 4-1/2" casing using 10# mud.
- Spotted 25 sack cement plug at 500' (Bottom of 7" casing)
- Put 10 sack cement plug in top of hole and set 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cliff Chapman TITLE Petroleum Engineer DATE March 20, 1968

APPROVED BY [Signature] TITLE DATE 1968

CONDITIONS OF APPROVAL, IF ANY: