



TONY ANAYA
GOVERNOR

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT
OIL CONSERVATION DIVISION
ARTESIA DISTRICT OFFICE

February 3, 1986

P.O. DRAWER DD
ARTESIA, NEW MEXICO 88210
(505) 748-1283

Arch Petroleum Inc.
777 Taylor St., Suite 2-A
Ft. Worth, TX 76102

Attention: Scott Noles

Dear Mr. Noles,

As per our telephone conversation today, the following is a plugging procedure for Resler State #6 Ut.D-32-18-28.

4 1/2" casing at 1956 ft. cemented with 125 Sx. T.D. @ 2014'.

1. 25 Sx plug @ 2000'-1900' and tag.
2. Run Cement Bond Log and find T.O.C.
3. Load hole with mud.
4. 25 Sx plug @ T.O.C.
5. 25 Sx plug in and out of 4 1/2" casing at base of salt and tag.
6. 25 Sx plug in and out of 4 1/2" casing at top of salt and tag.
7. 25 Sx plug in and out of 4 1/2" casing @ shoe of surface pipe and tag.
8. 10 Sx surface plug.

Our records do not show any surface casing. This plugging procedure is all I can give with the information available to me.

Sincerely,

Mike Williams
Oil & Gas Inspector