

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

**RECEIVED**  
NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

OCT 14 1969

**O. C. C.**  
**ARTESIA, OFFICE**

5a. Indicate Type of Lease  
State ☒ Fee ☐

5. State Oil & Gas Lease No.

**SUNDRY NOTICES AND REPORTS ON WELLS**

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water injection</b>	7. Unit Agreement Name
2. Name of Operator <b>American Petrofina Company of Texas</b>	8. Farm or Lease Name <b>Cowell State</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>K</b> , <b>1572</b> FEET FROM THE <b>South</b> LINE AND <b>1549</b> FEET FROM THE <b>West</b> LINE, SECTION <b>4</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.	10. Field and Pool, or Wildcat <b>Artesia</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3663 Gr.</b>	12. County <b>Eddy</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Start work approximately 10/20/69**

1. Run 2" EUE tubing and spot 50 sk cement on bottom (TD 2320) using mud laden fluid as displacing medium.
2. Cut off 5-1/2" casing at 1700'.
3. Spot 25 sk cement plug at 5-1/2" casing stub. *on at Top of Queen approx. 1420*
4. Spot 25 sk cement plug at 651' (bottom of 7" casing).
5. Cut off 7" casing at 554' and spot 25 sk cement plug at 554'. *at approx. 330*
6. Place 5 sk cement plug at surface and set 4" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J.M. Denson TITLE Asst. Dist. Mgr. of Prod. DATE October 13, 1969

APPROVED BY W.A. Grasset TITLE OIL AND GAS INSPECTOR

DATE OCT 17 1969

CONDITIONS OF APPROVAL, IF ANY: as noted above