NO. OF COPIES RECEIVED			Form C-103
DISTRIBUTION	3		Supercades Old
SANTA FE		NEW MEXICO OIL CONSERVATION COMMISSI	C-102 and C-103  Effective 1-1-65
FILE	1/1-		
U.S.G.S.	+	DEC 3 0 1970	5a. Indicate Type of Lease
LAND OFFICE	1. 1. 1		State X Fee
OPERATOR	1	<b>D.</b> c. c.	5. State Oil & Gas Lease No.
		A 7 1 7 7 7 7 1	703
(DO NOT USE THIS F	SUNDRY	NOTICES AND REPORTS ON WELLS OSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESE N FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
USE	"APPLICATIO	N FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)	
OIL GAS		OTHER-	7. Unit Agreement Name
. Name of Operator		OTHER-	8. Farm or Lease Name
AMERICAN PETROP	THA COM	ANY OF THYAS	
. Address of Operator	TABLE AND	MI OF IMPRO	Levers State 9. Well No.
Box 1311, Big	Spring,	Texas 79720	•
, Location of Well			10. Field and Pool, or Wildcat
UNIT LETTER	1	082 FEET FROM THE South LINE AND 1562	<b>)</b>
		LINE AND	FEET FROM
THE <b>Last</b>	LINE, SECTION	4 TOWNSHIP 185 RANGE 28E	NMPM.
		15. Elevation (Show whether DF, RT, GR, etc.)	12. County
711111111111111111111111111111111111111	7//////	3654 GR	Zády ()))))
) <b>.</b>	Check Ap	ppropriate Box To Indicate Nature of Notice, Re	eport or Other Data
NOTI	CE OF INT		JBSEQUENT REPORT OF:
_	_		
ERFORM REMEDIAL WORK		PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
_	_		
EMPORARILY ABANDON		COMMENCE DRILLING OPN	S. PLUG AND ABANDONMENT
<del>-</del>		COMMENCE DRILLING OPN CHANGE PLANS  CASING TEST AND CEMENT	- TOO AND ABANDONMENT
ULL OR ALTER CASING		[-7]	T JQB
other		CHANGE PLANS CASING TEST AND CEMENT OTHER  attions (Clearly state all pertinent details, and give pertinent da	T JOB
7. Describe Proposed or Cowork) SEE RULE 1103.  Start work appropriate Spot 50 sx cements fluid as displace Spot 25 sx cements.  Pull 8-5/8" cast	oximatel nt plug sting med nt plug sting.	casing test and cement other	ties, including estimated date of starting any proposed inguising mud laden
other  7. Describe Proposed or Cowork) SEE RULE 1103.  Start work appropriate the second seco	oximatel nt plug cing med nt plug ling. mut plug	casing test and cement other.  other  ations (Clearly state all pertinent details, and give pertinent day 1-14-71  on bottom (TD 2416) through 2" EUE tub  fum.  at 850 (Bottom of 8-5/8" casing)  in top of 10-3/4" casing and set 4-1/	ties, including estimated date of starting any proposing using mid laden  2" pipe marker.  Production DATE December 29, 1970
other  ot	oximatel nt plug cing med nt plug ling. mut plug	casing test and cement other.  other  ations (Clearly state all pertinent details, and give pertinent day 1-14-71  on bottom (TD 2416) through 2" EUE tub  fum.  at 850 (Bottom of 8-5/8" casing)  in top of 10-3/4" casing and set 4-1/	ping using mid laden  2" pipe marker.  Production DATE December 29, 1970
other	oximatel nt plug cing med nt plug ling. mut plug	change plans  ch	ping using mid laden  2" pipe marker.  Production DATE December 29, 1970