

TOPS

|| ← 60' Surface plug

Assume no cut

8 5/8" @ 760'
CMT Records
Unavailable

← shoe plug
710' to 810' TAG

1813' ← TOC calc @ 50%

S 1/2" @ 2290'
1255x
Est. 7 7/8 hole

PBTD 2305'
TDA 7335'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

WALA