

N. M. O. C. C. Co.
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRI-DATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 061701

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Anadarko Production Company

3. ADDRESS OF OPERATOR

P. O. Box 67, Loco Hills, New Mexico 88255, U. S. C.

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

2310' FSL & 2310' FWL
Sec. 8-18S-29E
Eddy County, New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3518' DF

7. UNIT AGREEMENT NAME

Hallard Grayburg
San Andres Unit

8. FARM OR LEASE NAME

Tract No. 14

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Loco Hills Queen
Grayburg San Andres

11. SEC., T., R., E., OR BLK. AND
SURVEY OR AREA

8 - 18S - 29E

12. COUNTY OR PARISH

Eddy

13. STATE

N. Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

PULL OR ALTER CASING ☐

FRACTURE TREAT ☐

MULTIPLE COMPLETE ☐

SHOOT OR ACIDIZE ☐

ABANDON* ☒

REPAIR WELL ☐

CHANGE PLANS ☐

(Other) ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

REPAIRING WELL ☐

FRACTURE TREATMENT ☐

ALTERING CASING ☐

SHOOTING OR ACIDIZING ☐

ABANDONMENT* ☐

(Other) ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

1. Trip in hole w/6 1/4" bit. Tag top of fish @ 2216'. Trip out of hole w/bit.
2. Trip in hole w/7" tension packer on 2 3/8" tubing. Set packer @ 2200'. Establish an injection rate & pressure through 3" tubing 2216' to 2371'.
3. Trip in hole w/7" Halliburton cement retainer. Set retainer @ 2200'. Squeeze O. H. Section from 2360' to 2660' w/265 sx cement. Pump 35sx plug on top of retainer.
4. ~~Trip in hole w/7" Halliburton cement retainer. Set retainer @ 2200'. Circulate hole from 2200' to surface w/mud laden fluid.~~
5. ~~Squeeze O. H. Section from 2360' to 2660' w/265 sx cement.~~
6. ~~Spot 35 sx cement plug on top of cement retainer from 2200' to 2100'.~~
7. Shoot off 7" casing @ free point.
8. Spot 35 sx cement plug 50' in and 50' out of 7" casing stub.
9. Spot 35 sx cement plug 50' below and 50' above base of salt @ 750'.
10. Spot 35 sx cement plug 50' in and 50' out of 8 5/8" surface casing @ 330'.
11. Spot 10 sx cement plug @ surface.
12. Erect dry hole marker and clean location.

18. I hereby certify that the foregoing is true and correct

SIGNED

Original Signed by
J. E. Buckles

TITLE

Area Supervisor

DATE

July 9, 1974

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

JUL 25 1974
R. L. BEEKMAN
DISTRICT ENGINEER

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.