

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	☒
FILE	☒
U.S.G.S.	
LAND OFFICE	
GEORGE	☒

RECEIVED BY
OIL CONSERVATION DIVISION
MAR 21 1984
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501
O. D.
ARTESIA, OFFICE

Form C-103
Revised 10-1-77

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEFEER OR PLUG BACK TO A DIFFERENT RESERVOIR.
APPLICATION FOR PERMIT - L (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name Far West Loco Hills Sand Unit
2. Name of Operator Anadarko Production Company	8. Farm or Lease Name Tract No. 9
3. Address of Operator P. O. Drawer 130, Artesia, New Mexico 88210	9. Well No. 12
4. Location of Well UNIT LETTER E 1650 FEET FROM THE North LINE AND 330 FEET FROM THE West LINE, SECTION 9 TOWNSHIP 18S RANGE 29E N.M.P.M.	10. Field and Pool, or Wildcat Loco Hills-Queen-Grayburg-San Andres
11. Elevation (Show whether DF, RT, CR, etc.) 3506' GL	12. County Eddy

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in, rig up pulling unit.
2. Pump brine gel mix @ 25# gel/bbl of 10# brine from PBTD 2480' to surface.
3. Spot 200' Class C cement with 3% CaCl 100' above and 100' below Grayburg top @ 2312'.
4. GIH with perf guns and tag top of 1st plug; pull up and perf 4 holes @ 1044' (100' below Salt section).
5. Spot 200' cement from 1044' to 844' & squeeze half of plug out squeeze holes.
6. GIH with perf guns and tag top of 2nd plug; pull up and perf 4 holes @ 350' (top of Salt Section).
7. Circulate cement down 5 1/2" casing out holes @ 350' & up 8-5/8" casing to surface.
Note: This plug will cover top of Salt section & also serve as surface plug.
8. Cut off all casing & anchors below surface; set P & A marker; clean & level location.

Note: See Item #7 - If cannot establish circulation to surface, will spot 200' cement plug from 350' to 150' and squeeze half of plug out perfs; tag plug with wireline & set a 50' plug at surface.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mike Braswell TITLE Field Foreman DATE March 20, 1984

APPROVED BY Mike Williams TITLE OIL AND GAS INSPECTOR DATE MAR 28 1984

CONDITIONS OF APPROVAL, IF ANY:

Plugging

Subject	FWLHSU #9-12	Page No	Of
File		By	Jon
		Date	8-20-82

