

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB No. 1004-0135
Expires November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

5. Lease Serial No.

NM-021095

6. If Indian, Allottee or Tribe Name

N/A

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.

YATES A #8

9. API Well No.

30-015-04483

10. Field and Pool, or Exploratory Area

Loco Hills

QUEEN GRAYBURG, SAN ANDRES

11. County or Parish, State

EDDY COUNTY, NM

SUBMIT IN TRIPLICATE - Other Instructions on reverse side

1. Type of Well

☒ Oil Well

☐ Gas Well

☐ Other

2. Name of Operator

Yates Petroleum Corporation

3a. Address

105 S. 4th Street - Artesia, NM 88210

3b. Phone No. (include area code)

505-748-1471

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

990' FNL & 2231' FWL Section 6-T18S-R30E UNIT C

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Acidize

☐ Deepen

☐ Production (Start/Resume)

☐ Water Shut-Off

☐ Alter Casing

☐ Fracture Treat

☐ Reclamation

☐ Well Integrity

☐ Casing Repair

☐ New Construction

☐ Recomplete

☐ Other

☐ Change Plans

☒ Plug and Abandon

☐ Temporarily Abandon

☐ Convert to Injection

☐ Plug Back

☐ Water Disposal

YATES PETROLEUM CORPORATION RESPECTFULLY REQUESTS PERMISSION TO PLUG & ABANDON AS FOLLOWS:

NOTIFY NMOCD 24 HOURS BEFORE STARTING PLUGGING OPERATIONS.

NOTIFY BLM IN CARLSBAD 24 HOURS BEFORE STARTING PLUGGING OPERATIONS.

1. MIRU WSU & safety equipment. No casing recover will be attempted.

2. RU wireline; TIH w/ wireline, set CIBP @ 2690'; TOH. TIH w/ tubing, tag CIBP. Load hole w/ plugging mud; keep wellbore loaded w/ mud. Spot 35' Class C cement on top of CIBP.

3. TOH w/ tubing; MIRU wireline to perforate 7" casing w/ casing guns, 4 shots @ 1230' & @ 523'.

4. TIH w/ wireline; set cement retainer @ 1130', TOH. TIH w/ tubing. Load hole w/ plugging mud; sting into retainer & establish injection rate.

Squeeze w/ 45 sx Class C cement w/ 5#/sx salt. Leave 35' cement on top of retainer. TOH w/ Tubing.

5. TIH w/ WL; set retainer @ 423' - TOH. ND BOP'S, TIH w/ tubing. Load hole w/ plugging mud. Sting into retainer & establish circ. Squeeze w/ 60 sx Class C cement w/ 5#/sx salt from 523' to surface; leave 35' cement on retainer, TOH w/ tubing.

6. Spot 15 sk Class C cement plug @ surface.

7. Remove all surface equipment & weld dry hole marker per regulations.

I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Donna Clack

Signature

Title

Operations Technician

Date

5-7-02

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

Date

Conditions of approval, if any, are attached. Removal of this notice does not warrant or certify that the applicant holds legal or equitable title to these rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001 and Title 18 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.