

SOUTHERN UNION NO. 1

LOCATION: 330 FNL & 990 FEL Section 18-18-30

ELEVATION: 2522 G.L.

TOTAL DEPTH: 2824

INITIAL PRODUCTION: 4-19-62 for 40 BOPD

CASING: 8 5/8" @ 489 with 50 sacks
4 1/2" @ 2804 with 150 sacks (Estimated top of cement 2250')

PROCEDURE:

1. Flow down well.
2. Dig pit at well.
3. Pull rods and tubing.
4. Run cast iron plug and set at 2775'.
5. Clean up around location and cover oil. Plan to test Queen zone soon.