

N. M. O. C. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
SUBMIT IN TRIPLICATE
(Other instruction
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-028973-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

North Denson Queen Unit

8. FARM OR LEASE NAME

North Denson Queen Unit

9. WELL NO.

40

10. FIELD AND POOL, OR WILDCAT

Benson Queen Grayburg North

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 34, T-18S, R-30-E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐
2. NAME OF OPERATOR
TEXACO Inc.
3. ADDRESS OF OPERATOR
P. O. Box 728 - Hobbs, New Mexico 88240
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface Well is located 1820' FNL & 820' FNL of
Section 34, T-18-S, R-30-E, Unit Letter 'E', Eddy County,
New Mexico.

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3446' (GR)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☒
☐

PULL OR ALTER CASING

☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up. Pull rods and pump. Install BOP. Pull tubing.
2. Set packer. Spot acid over perforations 2845-3032'.
3. Acidize perforations w/2000 gals. 15% NE acid. Swab well.
4. Treat w/55 gals scale inhibitor mixed w/275 gals. treated fresh water.
5. Flush w/50 bbls. treated fresh water.
6. Run pumping equipment. Test and return to production.

RECEIVED

JUL 21 1976

O. C. C.
ARTESIA OFFICE

RECEIVED

JUL 19 1976

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE Asst. District Supt.

DATE 7-15-76

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

APPROVED
JUL 16 1976
F. L. BECKWITH
ACTING DISTRICT ENGINEER