

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN 7
(Other instru
verse side)LICATE*
S OR re-Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 029420 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Shelly Unit

8. FARM OR LEASE NAME

Shelly Unit

9. WELL NO.

94

10. FIELD AND POOL, OR WILDCAT

Grayburg-Jackson11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**Sec. 28-178-31E**

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico1. OIL ☒ GAS ☐
WELL WELL OTHER

2. NAME OF OPERATOR

SEKELY OIL COMPANY

3. ADDRESS OF OPERATOR

P. O. Box 730 - Hobbs, New Mexico 882404. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface**1980' FNL & 1980' FNL Sec. 28-178-31E**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3600' DW

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well is presently producing from open hole section 3662-3767' of the San Andres Formation.**We propose to perforate and treat as follows:**

1. Move in and rig up Workover Rig.
2. Pull rods and lower tubing to check for fill-up.
3. Clean well out if necessary.
4. Run Celler Log.
5. Selectively perforate 5-1/2" OD casing from 3294' to 3615' with a total of 18 shots.
6. Isolate and treat through 5-1/2" OD casing perfs. 3294-3615' with 1250 gallons regular acid and ball sealers.
7. Isolate and treat through 5-1/2" OD casing perfs. 3294-3615' with 20,000 gallons water and 20,000# 20/40 sand.
8. Run tubing and pull Retrieval Bridge Plug.
9. Run tubing and rods and return well to a producing status.

18. I hereby certify that the foregoing is true and correct

SIGNATURE **V. E. Blalock**TITLE **District Superintendent**DATE **November 29, 1967**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.