

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN
(Other instru
verse side)LICATE*
is on re-Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.**LC 029420 (b)**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Shelly Unit

8. FARM OR LEASE NAME

Shelly Unit

9. WELL NO.

88

10. FIELD AND POOL, OR WILDCAT

Grayburg - Jackson11. SEC., T., R., M., OR BLM. AND
SURVEY OR AREA**Sec. 28-17S-31E**

12. COUNTY OR PARISH 13. STATE

Elddy**New Mexico****SUNDRY NOTICES AND REPORTS ON WELLS**
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

SEKELY OIL COMPANY

3. ADDRESS OF OPERATOR

P. O. Box 730 - Hobbs, New Mexico 882404. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface**1900' FSL & 1900' FSL Sec. 28-17S-31E**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3783' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☒PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☐CHANGE PLANS ☐**Clean out and Perforate and Treat**

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well is presently shut in. The well was produced from 3-1/2" OD casing perforations 3425-3590' (intervals) of the San Andres Formation.

We propose to drill out cement and bridge plug and perforate.

1. Move in and rig up Workover Rig.
2. Pull rods and tubing.
3. Run drill pipe with bit and drill out cement and bridge plug.
4. Clean well out to total depth of 3810'.
5. Selectively perforate 3-1/2" OD casing from 3338-3624' with a total of 113 shots.
6. Isolate and treat through 3-1/2" OD casing perforations 3607-3634' with 500 gallons acid.
7. Isolate and treat through 3-1/2" OD casing perforations 3492-3544' with 1000 gallons acid.
8. Isolate and treat through 3-1/2" OD casing perforations 3338-3411' with 1000 gallons acid.
9. Pull tubing and Retrievable Bridge Plug.
10. This well will be converted to a Water Injection Well at a later date.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE **District Superintendent**DATE **November 29, 1967**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.